

Removing a Metal Bracelet or Expansion Watch Band:



Optional Tip: Opening the bracelet to lay flat will make the process easier. To do this, remove the spring bar from the clasp. Use your spring bar tool (the push pin end) to depress the spring bar and release it from the clasp.



We recommend covering the lugs (minus lug holes) with masking or painter's tape to avoid potential scratching from the tools. Lay watch face down on the towel. Insert the forked end of the spring bar tool into the small gap where the spring bar is visible to catch the shoulder (ridge) of the spring bar.



Depress the spring bar by applying pressure with the tool towards the watch band and away from the watch case. When the spring bar is clear of the lug, that side of the band will drop down and out of the watch case. You may need to depress both sides of the spring bar at the same time to gently wiggle the band out. Metal bands tend to fit tighter in the lugs.



Slide watch around and repeat Steps 2-3 to the other side of the watch band. You're all done! If the spring bars are in good condition after removal they can be re-used on the replacement band.